

MiniRaQ^(TM*) Installation Overview


Congratulations on your purchase of the MiniRaQ^(TM) vertical rack system. The MiniRaQ^(TM) is available in 4U, 6U and 8U sizes based on size and usage restrictions for a variety of applications. The MiniRaQ^(TM) is designed from heavy gauge steel and finished to last a lifetime. It is designed to hold up to 400 pounds when properly installed for your most demanding needs such as extended runtime battery back up systems, low profile power distribution transformers, POE equipment and many other rack mountable products.



Warning For installing the MiniRaQ^(TM) System into any other surface not specifically mentioned in this manual, please consult local building code requirements to insure safe and secure installation.

The MiniRaQ^(TM) System can be mounted on a variety of vertical substrates including wooden framing studs 16" on center, solid or block concrete walls, and approved plywood electrical panel or directly onto existing 2 Post racking. Please see detailed instructions on the following pages.

Mounting hardware is provided for installing into solid wall studs and #12-24 screws for mounting on 2 Post rack. The MiniRaQ^(TM) can even be mounted in a 2 Post rack Back-to-Back configuration if clearances allow, which may increase U space utilization in some instances.




All Trademarks are the property of their respective owners. *Patents pending.
BlackHawk Labs, LLC Copyright 2007

MiniRaQ^(TM) Detailed Installation Instructions

First confirm that the main back panel of the MiniRaQ^(TM) will be mounted onto a recommended surface and be sure proper hardware is available to proceed. Hardware is supplied for both 2 Post rack (kit contains 10 #12-24 relay rack screws) and wooden framing studs 16" on center (kit contains 10 #10 x 2" Stainless Steel screws). If installing into concrete or approved plywood electrical panel be sure to have appropriate 1/4" hexhead concrete screws**, lag bolt inserts* or toggle bolts* before continuing with installation.

Note *10 fasteners are recommended for full rated load
 **10 fasteners are recommended for full rated load

Mounting main back panel for MiniRaQ^(TM)



Close up detail of
 Mounting hole patterns
 for different hardware options
 Available to install the
 MiniRaQ^(TM) System

FIGURE 2

**2 Post Rack mounting option
 (Hole Pattern A).....Page 3**

**Mounting into 16 inches on center
 solid wood wall studs (Hole Pattern B).....Page 4**

**Mounting to Cinder Block or Approved
 Hollow Wall (Hole Pattern C).....Page 5**

**Mounting to Concrete Wall with
 Compression Lags (Hole Pattern C).....Page 6**

**Mounting to Concrete Wall with TAPCON® bolts
 (Hole Pattern C).....Page 6**

Bracket Installation Details.....Page 7

Specifications and Warranty Information.....Page 8

2 Post Rack mounting option (Hole Pattern A)

Using supplied #12-24 screws align and insert 1 screw. Do not fully tight screw but engaged enough to hold up back panel. Using integrated level, adjust panel and add second screw to opposite post. Add remaining 8 screws and then tighten all. Next go to bracket installation details (pg 7).

Begin installing #12-24 Screws at the top using the integrated Level to locate proper mounting pattern. 10 screws recommended for full payload rating of system.

Close up detail of 2-Post Mounting option





FIGURE 3

Close up detail of 16" Center to Center Mounting option

Locate solid studs, 16 inches on center before marking top two locations for pilot holes. Drill .156" at the top using the integrated level to locate proper mounting pattern.

Begin installing supplied screws in pilot holes at the top then drill and install remaining screws in the pattern. 10 screws recommended for full payload rating of system.



Mounting into 16 inches on center solid wood wall studs (Hole Pattern B)

Place the MiniRaQ(TM) main back panel against the wall in the preferred location. Confirm location of stud centers and for at least one TOP pilot hole. Drill pilot hole using 5/32" bit (not supplied). Place the first #10 wood screw through top slot B and insert screw most of the way into stud. Using integrated level, adjust panel and drill remaining TOP Pilot hole and insert screw most of the way into stud. All remaining pilot holes can be drilled and screws inserted into holes as above. Tighten all screws. Next go to bracket installation details (pg 7).

FIGURE 4

Mounting to Cinder Block or Approved Hollow Wall (Hole Pattern C)

Place the MiniRaQ^(TM) main back panel against the wall in the preferred location. Using integrated level, adjust panel to level then mark a minimum of the two top and two bottom 1/2 inch clearance holes (Hole C). Drill marked holes and apply Togglers® or other associated inserts as required. Lift main back panel and hand tighten bolts and fender washers (not supplied) most of the way into stud. Tighten all screws. Next go to bracket installation details (pg 7).



Note

An approved hollow wall application is considered to be either of the following; Cinder Block wall or NEC type 3/4" plywood electrical panel backing using toggle bolts is safe for full rated load of MiniRaQ^(TM) System.



Note

In the event that this bracket is to be mounted on a block wall 1/4" x 3" toggle bolts should be used to support it. It will be important that the hollow pocket in the block is located so that the toggle can open properly to support the weight. Toggle bolt clearance hole is 1/2" (bolts and washers not supplied; available for purchase separately).

This illustration shows recommended mounting pattern for concrete screws with fender washers




FIGURE 5

Mounting to Concrete Wall with Compression Lags (Hole Pattern C)

Place the MiniRaQ^(TM) main back panel against the wall in the preferred location. Refer to Figure 5 on Page 5 for correct mounting hole pattern.

Using integrated level, adjust panel and to level and mark a minimum of the two top and two bottom ½ inch clearance holes (Hole C) Drill marked holes as required and apply compression studs or other associated inserts as required. Lift main back panel and hand tighten bolts and fender washers (not supplied) most of the way into stud. Tighten all screws. Next go to bracket installation details (pg 7).

Mounting to Concrete Wall with TAPCON® bolts (Hole Pattern C)

Place the MiniRaQ^(TM) main back panel against the wall in the preferred location. Refer to Figure 5 on Page 5 for correct mounting hole pattern. Using integrated level, adjust panel and to level and mark a minimum of the two top, two bottom and two middle 1/2" clearance holes (Hole C) Drill 5/32" pilot holes for 3/16" bolts, or 3/16" for 1/4" bolts pilot holes as required by manufacturer. Apply TAPCON® or equivalent concrete double threaded screws. A minimum 2 1/4" length is recommended for full rated loading of MiniRaQ. Lift main back panel and hand tighten bolts and washers (not supplied) most of the way into wall. Tighten all screws. Next go to bracket installation details (pg 7).




Caution: The MiniRaQ^(TM) must be properly installed to a suitable surface and using recommended hardware per instructions provided.


Bracket Installation Details for MiniRaQ™ System

With the MiniRaQ™ main back panel mounted the left and right brackets can be set in place and secured. The MiniRaQ™ main back panel accommodates all brackets sizes available, 4U, 6U and 8U versions.

Proper orientation is required to secure brackets after engaging the tabs to allow safety screw placement.



Engage one bracket at a time confirming all tabs are nested into cutouts on MiniRaQ™ main back panel (1) and slide down to fully set bracket. The clearance hole in the bracket (2) should now align with a threaded hole in the MiniRaQ™ main back panel. Apply a #12-24 screw (supplied) and tighten. Repeat with opposite bracket.



MiniRaQTM Specifications

Item Measurement

Height: 19.25 in (489 mm)

Width: 19.00 in (483 mm)

Depth:

4U version: 9.50 in (241 mm)

6U version: 13.00 in (330 mm)

8U version: 16.50 in (419 mm)

Net Weight:

4U version: 13.0 lb (5.9 kg)

6U version: 16.0 lb (7.3 kg)

8U version: 19.0 lb (8.6 kg)

Maximum Equipment Depth 38.00 in (965 mm)

Effective Rack Mounting Space:

4U version 4U + 2U Patch Panel + 1U each on Sides = 8U

6U version 4U + 2U Patch Panel + 1U each on Sides = 10U

8U version 4U + 2U Patch Panel + 1U each on Sides = 12U

Total Equipment Weight Capacity: 400.00 lb (181.44 kg)

Material: Heavy Duty 14AWG Steel

Finish: Chip Resistant Black Powder Coat

Shipping Dimensions: 20 X 20 X 3 inches All Versions

Shipping Weight:

4U version: 15.0 lb (6.8 kg)

6U version: 18.0 lb (8.2 kg)

8U version: 21.0 lb (9.5 kg)

Pallet Quantity: 48

Specifications are subject to change.

BlackHawk Labs, LLC Limited Factory Warranty

The limited warranty provided by BlackHawk Labs, LLC (BHL) in this Statement of Limited Factory Warranty applies only to Products purchased for commercial or industrial use in the ordinary course of your business.

Terms of Warranty

BHL warrants its products to be free from defects in materials and workmanship for a period of five years (two years in Japan) from the date of purchase. Its obligation under this warranty is limited to repairing or replacing, at its sole discretion, any such defective products. This warranty does not apply to equipment that has been damaged by accident, negligence, or misapplication or has been altered or modified in any way. Repair or replacement of a defective product or part thereof does not extend the original warranty period. Any parts furnished under this warranty may be new or factory-reconditioned.

Non-transferable Warranty

This warranty applies only to the original purchaser who must have properly registered the product. Product may be registered at www.bhpower.com/support.

Exclusions

BHL shall not be liable under the warranty if its testing and examination disclose that the alleged defect in the product does not exist or was caused by end user's or any third person's misuse, negligence or improper installation. Further BHL shall not be liable under the warranty for unauthorized attempts to repair or modify inappropriate on-site operating conditions, corrosive atmosphere, installation, a change in location or operating use, exposure to the elements, Acts of God, fire, theft, or installation contrary to BHL recommendations or specifications or in any event if the BHL serial number has been altered, defaced, or removed, or any other cause beyond the range of the intended use.

THERE ARE NO WARRANTIES, EXPRESS OR IMPLIED, BY OPERATION OF LAW OR OTHERWISE, OF PRODUCTS SOLD, SERVICED OR FURNISHED UNDER THIS AGREEMENT OR IN CONNECTION HERewith. BHL DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY, SATISFACTION AND FITNESS FOR A PARTICULAR PURPOSE. BHL EXPRESS WARRANTIES WILL NOT BE ENLARGED, DIMINISHED, OR AFFECTED BY AND NO OBLIGATION OR LIABILITY WILL ARISE OUT OF, BHL RENDERING OF TECHNICAL OR OTHER ADVICE OR SERVICE IN CONNECTION WITH THE PRODUCTS. THE FOREGOING WARRANTIES AND REMEDIES ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES AND REMEDIES. THE WARRANTIES SET FORTH ABOVE CONSTITUTE BHL SOLE LIABILITY AND PURCHASER'S EXCLUSIVE REMEDY FOR ANY BREACH OF SUCH WARRANTIES. BHL WARRANTIES RUN ONLY TO PURCHASER AND ARE NOT EXTENDED TO ANY THIRD PARTIES.

BHL WILL IN NO WAY BE LIABLE FOR ANY FORM OF INDIRECT, SPECIAL, CONSEQUENTIAL OR PUNITIVE DAMAGES, ARISING OUT OF THE USE, SERVICE OR INSTALLATION, OF THE PRODUCTS, WHETHER SUCH DAMAGES ARISE IN CONTRACT OR TORT, IRRESPECTIVE OF FAULT, NEGLIGENCE OR STRICT LIABILITY OR WHETHER BHL HAS BEEN ADVISED IN ADVANCE OF THE POSSIBILITY OF SUCH DAMAGES. SPECIFICALLY, BHL IS NOT LIABLE FOR ANY COSTS, SUCH AS LOST PROFITS OR REVENUE, LOSS OF EQUIPMENT, LOSS OF USE OF EQUIPMENT, LOSS OF SOFTWARE, LOSS OF DATA, COSTS OF SUBSTITUANTS, CLAIMS BY THIRD PARTIES, OR OTHERWISE.

NO SALESMAN, EMPLOYEE OR AGENT OF BHL IS AUTHORIZED TO ADD TO OR VARY THE TERMS OF THIS WARRANTY. WARRANTY TERMS MAY BE MODIFIED, IF AT ALL, ONLY IN WRITING SIGNED BY AN BHL OFFICER AND LEGAL DEPARTMENT.

Warranty Claims

Customers with warranty claims issues may access the BHL worldwide customer support network by visiting www.bhpower.com/support.

BHL Customer Support

Customer support for this or any other BHL product is available at no charge in any of the following ways:

- Visit www.MiniRaQ.com website to access documents and to submit customer support requests.
- www.bhpower.com (Corporate Headquarters)

Customer Support Line

877-427-2522 (toll free)

BHL headquarters USA

BlackHawk Labs, LLC
829 W. Stadium Lane, Unit B
Sacramento, CA 95834

Please recycle packaging materials

Entire contents copyright 2007 BlackHawk Labs, LLC. All rights reserved.

Reproduction in whole or in part without permission is prohibited. BHL, the BHL logo, and MiniRaQ are trademarks of BlackHawk Labs, LLC. All other trademarks, product names, and corporate names are the property of their respective owners and are used for informational purposes only.